

Installation Instructions

Product: *CraftCork*
Z-C30 and Z-C40 Rolled Cork

Note: Read the entire Installation Instructions before beginning.

Materials required:

- ✓ CraftCork
- ✓ Adhesive
- ✓ Metal straight edge or ruler
- ✓ Utility knife
- ✓ Rubber gloves
- ✓ Drop cloth

Preparing the substrate:

Inspect the substrate to be sure it is sound and free of dirt, oil, loose debris, or loose paint.

Preparing protection:

Protect the floor with a drop cloth and your hands with rubber gloves.

Preparing the cork:

Unroll the CraftCork and cut to the required size.

Applying adhesive to the substrate:

Apply adhesive to the substrate using the adhesive manufacturer's recommended method.

Installation:

Attach the first piece of CraftCork to the surface and smooth in place with a firm pressure to ensure a good bond. Install the remaining pieces of CraftCork in the same manner, aligning the edges as you go.

Trim CraftCork straight along any edge (window molding, door molding, corner, etc.) with a metal straight edge and a utility knife.

If a section of CraftCork becomes nicked or otherwise damaged, remove the damaged area with a utility knife and replace with a new piece of CraftCork. If done properly, the cut will be nearly invisible.