

Application Instructions

Product: SR Wood Wall Primer
Substrate: Drywall

Note: Read the entire Application Instructions before beginning.

The installer plays a critical role in the application of this product – experience is recommended.

Selecting Installers:

It is recommended to use an installer who has experience in installing real wood wallcovering. If one is not available, it is recommended that the chosen installer produce a mock-up, completing the entire procedure with a small sample.

Extreme humidity conditions should be avoided.

Controlling Locations:

Wood wallcovering is designed to function in a climate-controlled environment. Abrupt changes in temperature levels and extremes in humidity levels can cause damage. Wood wallcovering is not designed for areas including, but not limited to, those with exposure to spas, saunas, indoor pools, or outdoor atmosphere, nor areas which experience large swings in humidity.

Moisture content of the drywall should never exceed 10%.

Preparing the walls:

Use a moisture meter to test the moisture content of the drywall, ensuring that it does not exceed 10%. It is very important that the room's temperature and humidity remain constant until the product is sealed and finished. All drywall to which SR Wood Wall Primer is to be applied is to be free of dirt, dust, and defect, including voids and raises. A non-flat surface may result in imperfections.

100% coverage is required.

Application

Thoroughly stir before using. Do not dilute. Evenly apply one coat to wall surfaces using a roller. Coverage is approximately 400 square feet per gallon. Allow a minimum of 8 hours for drying before continuing. This product is intended to seal the drywall prior to the application of SR Wood Wallcovering Adhesive.

Questions?

If you have any questions regarding this application, contact your distributor. Visit www.srwoodinc.com for additional product information.